

Product data sheet

1-gang rocker with symbol "light"



Reference number

GCR 2990 L

1-gang rocker with symbol "light"

for switch ref.-no.: 501 U, 502 U, 503 U, 506 U, 507 U, 501-20 U, 506-20 U, 507-20 U
 for push-button ref.-no.: 531 U, 532 U, 533 U, 533-2 U

Spare part:

holder plate ref.-no.: CD 90 HP

For illuminated inserts use rocker with lens ref.-no.: ..KO...

Metal versions

Colour:

chrome

Material:

metal, chromium-plated
