

# Product data sheet

1-gang multi push-button (insert)



### Reference number

### 531-41 U

## 1-gang multi push-button 10 A / 250 V ~ (insert)

with screw terminals for rigid and flexible wires up to 2.5 mm<sup>2</sup>

without claws: ref.-no. with additional "E", e.g.: 531-41 EU

When the upper or lower half of the rocker is actuated, two contacts are closed simultaneously.

Especially designed as controller for wirings with relays, e.g. in combination with relay station ref.-no. RS 8 REGHE.

No electrical/mechanical interlocking.

Only recommended for CD and LS ranges (except metal versions).

#### Version

1-pole, 2-way push-button with 2 x 2 NO contacts, rocker in neutral position